

5.3 Replacement Parts - CER-12 with PC Board




Table 5-3 CER-12 Replacement Parts List

ITEM NO.	PART DESCRIPTION	PART NO.
1	HOUSING	44-CC9887
2	INDICATOR ASSY	56-DD14747
3	PLUG, TWIST LOCK	11-2001
3A	RECEPTACLE, TWIST LOCK	11-2010
4	CORD STRAIN RELIEF	17-0014
5	AC CORD ASSY	54-DD14856
6	PCB ASSEMBLY COMPLETE	56-BXM4872
7	EYEBOLT ASSEMBLY	54-DD14437
8	MAGNET ASSEMBLY W/ COIL	54-AA8075
9	THREAD LOCKING ADHESIVE	36-4015
10	ELECTRICAL ASSEMBLY	54-AA13486
11	OPERATING INSTRUCTIONS	37-DD12082
12	LIFTING GUIDELINES	37-DD12086
13	DANGER TAG	37-DD10963
14	DANGER TAG	37-DD10667
15	REMOTE ASSY	54-BXM2999-10
16	RIGID EPOXY PATCH KIT	06-DD14974
17	DROP RESISTOR REPAIR KIT	22-9178
18	CERAMIC LIFT RESISTOR REPAIR KIT	22-4360
19	SUPPRESSOR REPAIR KIT	23-6085